


AURORA SERIES QUICK START GUIDE


SIONYX Aurora Low-Light Camera

CAMERA SETUP



1. Pull latch down to remove viewfinder and access the battery compartment




2. Install battery and Micro SD card




3. Re-install viewfinder into the camera 4. Be sure the camera is set to OFF



5. Connect to the USB port by lifting rubber flap and charge the camera



6. Turn camera ON to any mode



OVER to camera setup continued



SIONYX


www.sionyx.com

+ CAMERA SETUP CONTINUED


7. Download SIONYX Aurora App from the App Store or Google Play.




8. Look into the viewfinder and rotate the diopter to bring the menu into focus. Your camera is now ready to use!



9. Rotate selector ring to change between Day, Twilight, and Night mode.



10. Additional settings can be accessed by long pressing the SET button on the top of the camera.



NOTE: Aurora Sport and Black models ship with Electronic Viewfinder Display Timeout set to 60 seconds to conserve battery when not in use. To disable, access second layer menu and select EVF Time Out.

100
Cummings
Center

Beverly, MA
01915 USA

SIONYX

www.sionyx.com